

Colossians 3:17



WESTERN INTERLOCK INC.

Paving Stone and Retaining Wall Systems Made for the Northwest.

PAVING STONE INSTALLATION

westerninterlock.com

Paving Stone Installation

Western Interlock paving stones are easily installed by homeowners. No prior experience is needed, just careful work and attention to detail. The following step-by-step instructions will help you achieve beautiful, long-lasting results.

STEP 1: Design

Measure out your area and draw a print of your project to determine what you will need.



STEP 2: Layout

Spray paint design outline on the ground with marking paint, adding an extra 6" on all sides that need edge restraint. Use a string and stake or a garden hose to mark radiused corners.



STEP 3: Get it square

Use a 3-4-5 right angle triangle to create a 90° corner to work from.



STEP 4: Set the grade

In order to properly shed water, your project needs to be sloped away from any structures. Use a level (line or laser), to establish a finished grade slope of at least 1/8" per linear foot.



STEP 5: Excavate

Excavate soil 6"-8" below finished grade depending on your application type. Areas that will receive vehicular traffic will require more excavation than areas that only receive pedestrian traffic.



STEP 6: Set the base

Place the $\frac{3}{4}$ minus gravel base, and compact to 3" from finished grade. The base needs to be smooth and even, as any surface imperfections will be obvious in the final product.



STEP 7: Screed the sand bed

Screed sand to a uniform 1" depth, using 1" thick material (such as 1" metal tubing, square or round, or $\frac{3}{4}$ " PVC pipe) for guides.



STEP 8: Lay the stones

Starting at the 90° corner, lay the pavers, keeping the joint lines straight by using a string line. Use the click-drop method to lay the stones. First *click* the stone tight against its neighbors, then *drop* it into place. Do not scoot pavers on the sand bed.



STEP 9: Install edge restraint

Set edge restraint on the gravel (remove excess bedding sand if necessary), secure using 10" spikes in every third hole, and compact the paving stones.



STEP 10: Finish

Sweep stone joints full of concrete sand and then compact again. Once you are done compacting, sweep off any remaining sand, pull up some chairs, and enjoy your new patio.



There is a Western Interlock dealer near you!

We invite you to stop by any of our retail facilities or dealerships to speak with a knowledgeable sales person, and to see our product in person.

Oregon

BANDON SUPPLY
541.347.2662 • Bandon

BEST BUY IN TOWN
503.645.6665 • Hillsboro

COPELAND LUMBER
541.997.8474 • Florence

DOUGLAS COUNTY FARMER'S CO-OP
800.452.0981 • Roseburg

LANE FOREST PRODUCTS
541.345.9085 • Eugene

LONG BROTHERS' BUILDING SUPPLY
503.981.4041 • Woodburn

VALLEY LANDSCAPE CENTER
503.692.0606 • Tualatin

BARK BOYS
503.378.7379 • Salem

CEMENT PRODUCTS
541.548.5910 • Redmond

COPELAND LUMBER
541.265.6640 • Newport

EASTERN OREGON RENTAL & SALES
541.963.8300 • La Grande

LANE FOREST PRODUCTS
541.345.9085 • Springfield

SCAPPOOSE SAND & GRAVEL
503.543.8821 • Scappoose

BEAR VALLEY NURSERY
541.996.2327 • Lincoln City

CLACKAMAS LANDSCAPE SUPPLY
503.656.2891 • Oregon City

COPELAND LUMBER
541.563.3166 • Waldport

KLAMATH STONE & MASONRY SUPPLY
541.273.7036 • Klamath Falls

LEAVE YOUR MARK
541.535.3445 • Phoenix

STONE DEPOT
503.465.1502 • Gresham

Washington

BLAKE TILE & STONE
360.681.2877 • Sequim

NKS STONES, INC
206.767.9776 • Seattle

SWANSON BARK
360.414.9663 • Longview

WESTERN MATERIALS
509.547.3301 • Pasco

WESTERN MATERIALS
509.575.3000 • Yakima

DOWELL COMPANY
253.852.1700 • Kent

NORTH BEND LANDSCAPE SUPPLY
425.888.6502 • North Bend

TACOMA WINSUPPLY
253.272.8445 • Tacoma

WESTERN MATERIALS
360.984.5097 • Vancouver

GIBSONS NURSERY
509.928.0973 • Spokane

SIMPLY ROCKS
360.863.3975 • Snohomish

UNION HILL HARDSCAPE & BRICK
425.318.5102 • Redmond

WESTERN MATERIALS
509.886.5182 • Wenatchee

WESTERN INTERLOCK RETAIL FACILITIES:

10095 Rickreall Rd, Rickreall, OR 97101

9145 Fasset St., Olympia, WA 98512



Paving Stone & Retaining Wall Systems Made for the Northwest.

503.623.9084 OR
360.878.9301 WA

westerninterlock.com